

Programmable Relays Quick Start Guide

1. Introduction

Dear Customer! Thank you for your purchase in TME! To protect the environment we have prepared for you this quick start guide. Before operating the unit, please read it carefully. Please visit www.tme.eu Illustrations in this manual are only example images and may differ from the actual item. It does not change their main characteristics.

2. Application

The device is designed for use in industrial automation systems.

3. Unit setup and operation

- Install the device according to the type of the housing.
- Connect the wires to the terminals according to manufacturer's scheme.
- Turn on the power.

4. Precautions

- During installation work pay attention to discharge electrostatic charges from yourself before touching the device.
- Power cords and protection cables should be installed in such way that the existing capacity and inductance do not jeopardize the functioning of the automation system.
- Automation equipment and related operating elements have to be installed in such way that they are well protected against unintentional use.
- Use appropriate hardware and software protection that in case of a break in input or output signal wires undefined states of the automation devices do not occur.
- Equipment designed for installation in casing or cabinets can be used and operated only if is built in.



Transfer Multisort Elektronik Sp. z o.o.

ul. Ustronna 41, 93-350 Łódź, Poland, correspondence address: 90-951 Łódź 40, PO BOX 2071
tel. +48 42 645 54 44, fax +48 42 645 54 70, export@tme.eu, www.tme.eu

VAT ID: PL7290108984, REGON (NACE): 473171710, District Court for Łódź-Śródmieście, NCR: 0000165815, initial capital: 3 300 000 PLN