

Inverters Quick Start Guide

1. Introduction

Dear Customer! Thank you for your purchase in TME! To protect the environment we have prepared for you this quick start guide. Before operating the unit, please read it carefully. Please visit www.tme.eu Illustrations in this manual are only example images and may differ from the actual item. It does not change their main characteristics.

2. Application

This device is used to control the rotation speed of AC motors etc.

3. Unit setup and operation

- Connect according to the manufacturer's instructions.

4. Precautions

- This device should be installed, adjusted, and serviced by qualified personnel familiar with the construction and operation and the hazards involved. Disregarding this rule may result in injury.
- User is responsible for the proper selection of machinery and equipment and application of propulsion systems. Used machinery, equipment and materials should ensure the safe operation of the entire drive. Incorrect selection of the device may result in damage to the propulsion system and can lead to personal injury .
- Danger of electric shock, disconnect power supply before checking the device.
- After turning off the device wait 5 minutes before making any modifications to wiring connections or performing an inspection. Dangerous voltage may still be present in some components of the device.



Transfer Multisort Elektronik Sp. z o.o.

ul. Ustronna 41, 93-350 Łódź, Poland, correspondence address: 90-951 Łódź 40, PO BOX 2071
tel. +48 42 645 54 44, fax +48 42 645 54 70, export@tme.eu, www.tme.eu

VAT ID: PL7290108984, REGON (NACE): 473171710, District Court for Łódź-Śródmieście, NCR: 0000165815, initial capital: 3 300 000 PLN