

# Installation Instructions HDO Oscilloscope Rackmount Accessory



#### **HDO Oscilloscope Rackmount Accessory Installation Instructions**

© 2013 Teledyne LeCroy, Inc. All rights reserved.

Unauthorized duplication of Teledyne LeCroy documentation materials other than for internal sales and distribution purposes is strictly prohibited. However, clients are encouraged to distribute and duplicate Teledyne LeCroy documentation for their own internal educational purposes.

HDO Oscilloscope and Teledyne LeCroy are registered trademarks of Teledyne LeCroy, Inc. Windows is a registered trademark of Microsoft Corporation. Other product or brand names are trademarks or requested trademarks of their respective holders. Information in this publication supersedes all earlier versions. Specifications are subject to change without notice.

922646-00 Rev A

February 2013


## Welcome


Thank you for purchasing a Rackmount Accessory for the Teledyne LeCroy HDO Oscilloscope. The following topics explain proper installation and usage procedures.

Upon receiving your shipment, remove all parts from the packaging. Refer to **Package Contents** to ensure that all items have shipped correctly.

Check the **Pre-Installation Requirements**, then follow the **Installation Procedure** to set up your Rackmount properly.

When fully assembled, rackmount accessory dimensions are 7 RU (311 mm or 12.25 inches) vertical, 480 mm horizontal, and 240 mm deep (including handles).





# **Package Contents**


Please take a moment to ensure all parts have correctly shipped with your Rackmount:




M4 X 10 Phillips Screw (15)




M5 X 12 Phillips Screw (4)




12.2mm Front Handle (2)




Top Bracket (1)




Face Plate (1)



Left Wall (1)



Right Wall (1)



Tray Base (1)

Contact the **Teledyne LeCroy Service Center** nearest to you if any parts are missing or damaged.

**NOTE**: Parts are shown in this manual using the aforementioned names. See the **Part Reference Table** for the exact Teledyne LeCroy part numbers when ordering replacements.

## **Part Reference Table**

Use the following numbers when ordering replacement parts.

Description	Teledyne LeCroy Part Number	Qty. Per Unit
M4 X 10 Phillips Screw	550441110	15
M5 X 12 Phillips Screw	42A000003090	4
12.2mm Front Handle	42A0000002918	2
Top Bracket	922666-00	1
Face Plate	922476-00	1
Left Wall	922477-00	1
Right Wall	922478-00	1
Tray Base	922475-00	1
Installation Instructions	922646-00	1

## **Pre-Installation Requirements**


### **Tools**

A standard Phillips (#2 head) screwdriver is required for the light assembly of your HDO Oscilloscope Rackmount.

## Oscilloscope

Be sure to prepare your HDO oscilloscope for rack mounting by performing the following:


- **Power down** the oscilloscope.
- Unplug the AC Power Plug from the back panel of the oscilloscope.
- With the feet rotated to the position shown below, flip up the feet of your oscilloscope so the instrument lies flat.




6 922646-00 Rev A

## **Installation Procedure**


1. Attach the two 12.2mm Front Handles to the Face Plate using the four provided M5 X 12 Phillips Screws.




2. Attach the Face Plate, Left and Right Walls to the Tray Base using 11 of the 15 provided M4 X 10 Phillips Screws.



3. With your oscilloscope prepared according to the **Pre-Installation Requirements**, carefully pick up and lower the oscilloscope into the assembled **Face Plate**, **Left and Right Walls**, and **Tray Base**.




Seat the instrument into the Tray Base, centering the front of the unit into the Face Plate opening. Position the feet of the oscilloscope in front of the stiffening rib located toward the back of the Tray Base.




8 922646-00 Rev A

4. Align the slots on the **Top Bracket** with the positioning pins inside the **Left and Right Walls**, then rotate the Top Bracket forward until it rests on top of the oscilloscope and the screw holes align.



5. Use the remaining four M4 X 10 Phillips Screws to attach the Top Bracket to the Left and Right Walls.



## **Teledyne LeCroy Service Centers**

#### **United States and Canada - World Wide Corporate Office**

Teledyne LeCroy Corporation 700 Chestnut Ridge Road Chestnut Ridge, NY, 10977-6499, USA Ph: 800-553-2769 / 845-425-2000

FAX: 845-578-5985 teledynelecroy.com

**Support:** 

contact.corp@teledynelecroy.com

Sales:

customersupport@teledynelecroy.com

#### **United States - Protocol Solutions Group**

Teledyne LeCroy Corporation 3385 Scott Boulevard Santa Clara, CA, 95054, USA FAX: 408-727-0800 teledynelecroy.com

**Sales and Service:** Ph: 800-909-7211 / 408-727-6600

contact.corp@teledynelecroy.com

Support:

Ph: 800-909-7112 / 408-653-1260 psgsupport@teledynelecroy.com

#### **European Headquarters**

Teledyne LeCroy SA 4, Rue Moïse Marcinhes Case postale 341 1217 Meyrin 1 Geneva, Switzerland

Ph: + 41 22 719 2228 / + 41 22 719 2323 / + 41 22 719 2277

FAX: +41 22 719 2233

contact.sa@teledynelecroy.com

applications.indirect@teledynelecroy.com

teledynelecroy.com/europe

Protocol Analyzers: Ph: +44 12 765 03971

#### Singapore, Oscilloscopes

Teledyne LeCroy Singapore Pte Ltd. Blk 750C Chai Chee Road #02-08 Technopark @ Chai Chee Singapore 469003

Ph: ++ 65 64424880 FAX: ++ 65 64427811

10 922646-00 Rev A

#### Singapore, Protocol Analyzers

Genetron Singapore Pte Ltd. 37 Kallang Pudding Road, #08-08 Tong Lee Building Block B Singapore 349315 Ph: ++ 65 9760-4682

#### China

Teledyne LeCroy Corporation Beijing
Rm. 2001
Unit A, Horizon Plaza
No. 6, Zhichun Road, Haidian District
Beijing 100088, China
Ph: ++86 10 8280 0318 / ++86 10 8280 0319 / ++86 10 8280 0320
FAX:++86 10 8280 0316

Service:

Rm. 2002

Ph: ++86 10 8280 0245

#### **Taiwan**

LeColn Technology Co Ltd. Far East Century Park, C3, 9F No. 2, Chien-8th Road, Chung-Ho Dist., New Taipei City, Taiwan Ph: ++ 886 2 8226 1366

FAX: ++ 886 2 8226 1368

#### Korea

Teledyne LeCroy Korea 10th fl.Ildong Bldg. 968-5 Daechi-dong, Gangnam-gu Seoul 135-280, Korea Ph: ++ 82 2 3452 0400 FAX: ++ 82 2 3452 0490

#### Japan

Teledyne LeCroy Japan Hobunsya Funchu Bldg, 3F 3-11-5, Midori-cho, Fuchu-Shi Tokyo 183-0006, Japan Ph: ++ 81 4 2402 9400 FAX: ++ 81 4 2402 9586 teledynelecroy.com/japan



700 Chestnut Ridge Road Chestnut Ridge, NY 10977 USA

teledynelecroy.com