

DIN Rail Power Supplies Quick Start Guide


1. Introduction

Dear Customer! Thank you for your purchase in TME! To protect the environment we have prepared for you this quick start guide. Before operating the unit, please read it carefully. Please visit www.tme.eu Illustrations in this manual are only example images and may differ from the actual item. It does not change their main characteristics.

2. Application

Device mounted on a DIN rail designed to power equipment in industrial facilities.

3. Unit setup and operation



I - Power supply input

O - Power supply output

- Mount the power supply on a DIN rail.
- Connect the power supply and output cables to the appropriate terminals.
- Turn on the power.

4. Precautions



Transfer Multisort Elektronik Sp. z o.o.

ul. Ustronna 41, 93-350 Łódź, Poland, correspondence address: 90-951 Łódź 40, PO BOX 2071
tel. +48 42 645 54 44, fax +48 42 645 54 70, export@tme.eu, www.tme.eu

VAT ID: PL7290108984, REGON (NACE): 473171710, District Court for Łódź-Śródmieście, NCR: 0000165815, initial capital: 3 300 000 PLN

- Do not exceed the rated operating parameters.
- The device must be powered from the mains socket with protection circuit.
- Dangerous voltages may still exist in the power supply even after few minutes from turning off the power.
- There is a risk of injury from electric shock - do not touch the terminals when the power is on.
- Do not allow any liquids or objects to get into the device - it can cause electric shock or damage the device.
- Do not cover the vents - it can damage the device.
- The device may interfere with radio and television sensitive equipment located nearby.



Transfer Multisort Elektronik Sp. z o.o.

ul. Ustronna 41, 93-350 Łódź, Poland, correspondence address: 90-951 Łódź 40, PO BOX 2071
tel. +48 42 645 54 44, fax +48 42 645 54 70, export@tme.eu, www.tme.eu

VAT ID: PL7290108984, REGON (NACE): 473171710, District Court for Łódź-Śródmieście, NCR: 0000165815, initial capital: 3 300 000 PLN